


Annual Change + 0.2°E
VAR 6° E 2020



DEPARTURE

The normal taxi-route procedure is clockwise taxiing where parallel taxiways are established. Reference see AD 2 ESSA 2.20 Taxi Procedures. Pilots will receive instruction to change frequency between 121.705, 121.930 and 121.980 when crossing the area boundaries of Arlanda Ground. Depending on RWY's in use the areas of responsibility of Arlanda Ground vary. ACFT will receive first GND frequency to contact from Clearance Delivery.

Freq: 121,705

Freq: 121,930

Freq: 121,980

LEGEND

- Asphalt
- Buildings
- Water surface
- TWY bridge
- Communication borders
- Manoeuvring area

